

## Main Menu




## Introduction to Your TV Features

Here are some of the main features available to you.

- **Replay a program that aired up to 24 hours ago** – go back up to 24 hours ago in the TV Guide to watch or record a program
- **Pause Live TV** – you can always pause Live TV, but you have more options when you press the center circle “OK” button on your remote (including starting any program over from the beginning)
- **See the last 10 channels you watched** - while watching a program, press the center circle remote button and scroll down a few rows to display the “Last Watched” channel menu
- **Record** - what you are watching live or schedule a future recording from the TV Guide. You have 112 hours of recording space, and recordings are kept for 7 days

## Getting Started with the Remote Control Main Features



Key	Action
1	2 functions: 1) From full screen TV, displays main Menu 2) In a menu screen, backs up one menu screen
2	CH Up / Down
3	Exit to Roku Home screen
4	Program Options while watching full screen TV
5	Closed Captioning options

## Restart TV That You Missed

You can scroll back up to 24 hours in the TV Guide to watch or record a program you may have missed. The main Menu also has a “Restart TV” list of all the programs available to restart in the past 24 hours listed by channel number.



## How to See Your 10 Last Watched Channels


While watching a program, press the circle OK remote button and scroll down a few rows to display the below screen.



## How to Record


1. You can record the program you are watching live, as described above. You can record one episode or a series.
2. From the TV Guide, you can schedule to record a future program or go back in the TV Guide up to 24 hours to watch or record a program.

NOTE: Recordings are auto deleted in 7 days. You have 112 hours of recording space.




## Settings

From the Main Menu, select Settings to display these options.



## Create Favorite Channel Lists

Create as many favorite channel lists as you want.




## How to See Your Favorite Lists

### Option 1 -Sort Your TV Guide to Only Show Your Favorite List

In the TV Guide, on the remote long press for 2 seconds and release the Back button  to display the TV Guide with the option on top to filter by your favorite lists.




**Option 2 - Select All Channels from the Main Menu** to display the left screen view below. After you create favorite channel lists, for example “SPORTS”, you can switch to display your favorite “SPORTS” channel list here. Switch the list by using the remote left/right arrows.



## Changing Your Favorite Lists

### Option 1 - While Viewing Your Favorite Channel List in the TV Guide

Select a future program for the channel you want removed.



### Option 2 – Select “Channels” from the Main Menu

While viewing all channels or your favorite list, press and hold the OK button for 2 seconds and release the button to display the screen below. You can add to or remove the channel from your favorite list.

